

# PORTABLE LEEB HARDNESS TESTER

## METZ HT – 1



### SALIENT FEATURES

- Large LCD Display (28X64 dot matrix) showing hardness value, Direction of impact device, hardness scale, material, test Time for average and battery icon
- Direct Display of hardness in HV, HB, HRC, HRB, HRA and HS Scales.
- 7 types of impact devices can be attached for special application and need not to be recalibrated when changing them.
- the machine identify the type of impact device automatically
- Upto 600 groups (impact times: 32~1) of data can be stored in internal memory of the machine.
- Upper and lower limit of hardness can be preset, when the tested value exceeds the limits, alarm buzz automatically
- Back light on/off facility is given by pressing key to make machine convenient for use in poor light.
- User Calibration function.
- By Using Software, data can be transferred and saved in pc for future use

**METZER OPTO INC.**

Tower A-0007, ATS Bouquet, Sector - 132, NOIDA - 201305 (U.P)

🌐 [www.metzerlab.com](http://www.metzerlab.com)    ✉ [sales@metzermicroscope.com](mailto:sales@metzermicroscope.com)    ☎ +91 9897000955



Scan to download  
complete catalogue